



ANDERSON-NEGELE

Anderson Instrument Co., Inc.

156 Auriesville Rd.  
Fultonville, NY 12072

Phone: 518-922-5315 or 800-833-0081

















www.anderson-negele.com

# Technical Bulletin

AV-9000 / AV-9900 Chart Recorder  
Time Change

NOTE: Model AV-9900 ONLY

The chart rotation MUST be stopped. Time change not allowed while processing.

1.  to **SELECT** <->  
**CONFIGURATION**
2. 
3.  to **CONFIGURE** <->  
**INSTRUMENT SETTINGS**
4. 
5.  to **CURRENT TIME**  
**AM/PM** **XX:XX** **XX**
6.  **Cursor appears under hours**
7.  or  to change hours
8.  to program new hours
9.  or  to change minutes
10.  to program new minutes
11.  or  to change AM/PM
12.  to program AM/PM
13.  to return to main display