



Product Information TFP-41, -44, -51, -54, -61, -161, -164, -181, -184

FOOD

CLEANadapt

Temperature Sensor with G1/2" hygienic

Successor: TSMF

New, modular and better!

Application/Specified usage

- Temperature Measurement in vessels and pipes
- Front flush temperature measurement available

Application examples

- · Monitoring of CIP-/ SIP-process
- · Measurement in vessels with agitators with front flush version
- Temperature monitoring in milk vessels

Hygienic design/Process connection

- · Flow optimized, hygienic and easy sterilizable installation by using Negele weld-in sleeve, e.g. EMZ-132 or build-in system, e.g. EHG-... / 1/2"
- Additional process connections: adapters for Tri-Clamp, dairy flange (DIN 11851), Varivent, DRD, APV et al
- · Sealing system free of elastomers, the connection will be without gaps and crevices
- · Product contacting materials compliant to FDA
- · Sensor completely made of stainless steel resp. PEEK (front flush sensor)
- Conforming to 3-A Sanitary Standard 74-06 for front flush sensors

Features/Advantages

- · Front flush mounting possible
- Integrated transmitter optional
- Different electrical connections available


Options/Accessories

- 2 x Pt100 (not retrofittable)
- 2 x Pt100 with two transmitters (not retrofittable)
- Programmable transmitters MPU-4 as well as MPU-M with output 4...20 mA, 2-wire
- · Integrated transmitters for HART-protocol
- · Programming adapter MPU-P 9701
- · Integrated transmitter MPU-LCD with display in connecting head
- Pt100 chip with other classes of accuracy (1/3B, 1/10B)
- · Fast response sensor tip 3 mm and 4 mm
- Spacer for high temperature up to 250 °C
- permanent temperature up to 450 °C (on request)
- · Pre-assembled connecting cable for M12 plug
- · Fixed cable in other lengths and other material available

Authorizations









Temperature sensor TFP-41



PVC-cable with M12-connection



Accessories

PVC-cable with M12-connection made of 1.4305, IP 69 K, unshielded

M12-PVC / 4-5 m M12-PVC / 4-10 m M12-PVC / 4-25 m PVC-cable 4-pin, length 5 m PVC-cable 4-pin, length 10 m PVC-cable 4-pin, length 25 m

FOOD


2

Temperature sensor				
Process connection	thread	G1/2" combined with Negele weld-in sleeves, build-in systems, adapter sleeves		
Tightening torque	sensor sealing PEEK sensor sealing stainless steel	10 Nm 20 Nm		
Insertion length EL	TFP-41, -51, -61, -161, -181 TFP-44, -54, -164, -184	20500 mm front flush		
Materials	connecting head thermowell at TFP-44, -54, -164, -184	stainless steel 1.4301 (AISI 304) stainless steel 1.4404 (AISI 316L) PEEK		
Operating pressure	TFP-41, -51, -61, -161, -181 TFP-44, -54, -164, -184	50 bar maximum 10 bar maximum		
Temperature ranges	ambient sensor tip TFP-xx1 sensor tip TFP-xx4	-50+80 °C -50+250 °C -50+140 °C		
Sensing resistor	acc. to DIN EN 60751	Pt100		
Electrical connection	cable gland cable connection fixed cable 2.5 m fixed cable 2.5 m (≥ 90 °C)	M16 x 1,5 M12 plug 1.4301 (AISI 304), 4-pins LIYY 4 x 0,25 mm² PTFE 4 x 0,14 mm²		
Protection class		IP 69 K (with electrical connection M12 plug)		

Transmitter MPU-4, MPU-H, MPU-M				
Temperature ranges	ambient storage	-40+85 °C -55+90 °C		
Measuring ranges	MPU-4, MPU-H, MPU-M	standard: -1040 °C, 050 / 100 / 150 / 200 °C special ranges free programable		
Accuracy	input	< ±0.25 °C		
Temperature drift	zero, span	< 0.01 % / K		
Supply	MPU-4, MPU-H, MPU-M accuracy	835 V DC 0.01 % / V (reference: 12 V DC)		
Output	signal accuracy burden	analog 420 mA < \pm 0.1 % of measurement range < 600 Ω (at U _B = 24 V)		
Humidity	without condensation	098 %		


Accuracy classes of temperature sensors Tolerances for Pt100 acc. to DIN EN 60751					
Pt100	A	1/3 B	1/10 B		
0 °C / 100 Ω	±0,15 K / ±0,06 Ω	±0,10 K / ±0,04 Ω	±0,03 K / ±0,01 Ω		
100 °C / 138,5 Ω	±0,35 K / ±0,13 Ω	±0,27 K / ±0,10 Ω	±0,08 K / ±0,03 Ω		


3





FOOD

4











Dimensional Drawings

5



Sensor tip diameter and response time

All temperature sensors are available with smaller sensor tips, to ensure a shorter response time. The below-mentioned times were measured by emersing a temperature sensor from room temperature into boiling water.



FOOD

Conditions for a measuring point according to 3-A Sanitary Standard 74-06

- The sensors TFP-44, -54, -164, -184 conforming to the 3-A Sanitary Standard.
- The sensors are designed for CIP-/ SIP-cleaning. Maximum 140 °C / 120 minutes.
- Only with the build-in system CLEANadapt (EMZ, EMK, EHG with tube ≥ DN25, ISO 20 and G1", Adapter AMC and AMV) allowed.
- · Using the weld in sleeve EMZ, EMK the weld must comply to the requirements of the current 3-A Sanitary Standard.
- Mounting position, self draining and the position of the leackage hole must be in accordance to current 3-A Sanitary Standard.

Mechanical connection/Installation

 Use only Negele CLEANadapt system for safe operation of measuring point!

Transport/Storage



- · Do not store outside
- · Store in an area that is dry and dust-free
- · Do not expose to corrosive media
- · Protect against solar radiation
- · Avoid mechanical shock and vibration
- Storage temperature -55...+90 °C
- · Relative humidity max. 98%

Cleaning/Maintenance



• When using a pressure washer, do not point the nozzle directly at the electrical connections.

Reshipment

- Sensors shall be clean and free of media or heatconductive paste and must not be contaminated with dangerous media!
- Use suitable transport packaging only to avoid damage of the equipment!

Conventional usage



Not suitable for applications in explosive areas.
Not suitable for applications in safety-relevant system parts (SIL).

Standards and guidelines



• Compliance with the applicable regulations and directives is mandatory.

Note on CE




- Applicable directives: Electromagnetic Compatibility Directive 2014/30/EU
- Compliance with the applicable EU directives is identified by the CE label on the product.
- The operating company is responsible for complying with the guidelines applicable to the entire installation.



- Electrical devices should not be disposed of with household trash. They must be recycled in accordance with national laws and regulations.
- Take the device directly to a specialized recycling company and do not use municipal collection points.

7


Order code for version with 1 x Pt100



8

Order code for version with 2 x Pt100

- **TFP-41.2** (connecting head Ø 55 mm, 2 x Pt100, no transmitter possible!)
- **TFP-51.2** (connecting head Ø 55 mm, 2 x Pt100, with spacer, no transmitter possible!)
- **TFP-61** (higher connecting head Ø 55 mm, 2 x Pt100, prepared for 2 x transmitter)
- **TFP-61-H** (like TFP-61, but with spacer)
- **TFP-181.2** (connecting head Ø 18 mm, electrical connection 2.5 m PTFE-cable; other lengths: see at accessories)



NEGELE MESSTECHNIK GMBH Raiffeisenweg 7 87743 Egg an der Guenz Phone +49 (0) 83 33 . 92 04 - 0 Fax +49 (0) 83 33 . 92 04 - 49 sales@anderson-negele.com Tech. Support: support@anderson-negele.com Phone +49 (0) 83 33 . 92 04 - 720